## Wall Hood Flue Extension **BLACK WALL HOOD** 231/2" 313/8" 411/2" 513/8" 611/2" (1562) (597) (797)(1054) (1305) WITHOUT UPPER FLUE FLUE AT MINIMUM EXTENSION FLUE AT MAXIMUM EXTENSION ACCESSORY FLUE AT MINIMUM EXTENSION ACCESSORY FLUE AT MAXIMUM EXTENSION STAINLESS WALL HOOD 271/4" 351/8" 451/4" 551/8" 651/4" (692) (892) (1149) (1400) (1657) .......... WITHOUT UPPER FLUE FLUE AT MINIMUM EXTENSION FLUE AT MAXIMUM EXTENSION ACCESSORY FLUE AT MINIMUM EXTENSION ACCESSORY FLUE AT MAXIMUM EXTENSION **GLASS WALL HOOD** 231/2" 513/8" 313/8" 411/2" 61<sup>1</sup>/2" (1562) (797)(1054)(1305)WITHOUT UPPER FLUE FLUE AT MINIMUM EXTENSION FLUE AT MAXIMUM EXTENSION ACCESSORY FLUE AT MINIMUM EXTENSION ACCESSORY FLUE AT MAXIMUM EXTENSION

## Island Hood Flue Extension **BLACK ISLAND HOOD** 251/2" 257/8" 341/4" 481/2" 571/4" (1232) (1454) (648)(657) (870) WITHOUT UPPER FLUE FLUE AT MINIMUM EXTENSION FLUE AT MAXIMUM EXTENSION ACCESSORY FLUE AT MINIMUM EXTENSION ACCESSORY FLUE AT MAXIMUM EXTENSION STAINLESS ISLAND HOOD 291/4" 295/8" 521/4" 61" 38" (743) (752) (965) (1327) (1549) WITHOUT UPPER FLUE FLUE AT MINIMUM EXTENSION FLUE AT MAXIMUM EXTENSION ACCESSORY FLUE AT MINIMUM EXTENSION ACCESSORY FLUE AT MAXIMUM EXTENSION **GLASS ISLAND HOOD** 251/2" 257/8" 341/4" 481/2" 571/4" (1454) (657) (870) (1232)WITHOUT UPPER FLUE FLUE AT MINIMUM EXTENSION FLUE AT MAXIMUM EXTENSION ACCESSORY FLUE AT MINIMUM EXTENSION ACCESSORY FLUE AT MAXIMUM EXTENSION